



LED

LED Cube 285 IC

LED-UV irradiation chamber for large workpieces

Max. irradiation intensity: up to 3.000 mW/cm²

Wavelength: 365, 385, 395, 405 and 460 nm

Air cooled

System-Features

- Extremely long LED service life
- Available in different wavelengths
- Power control between 10 - 100 %
- Intelligent door-LED-connection

Advantages

- Homogenous irradiation
- Suitable for temperature sensitive materials
- No warm-up phase
- No stand-by time
- Lamp unit with different wavelengths easily exchangeable

LED Cube 285 IC

The LED Cube 285 IC is a UV irradiation chamber for larger workpieces / workpiece carriers which can be used in the laboratory or for manual production. By employing different LED units the emission range and the intensities are adjustable to various fields of application.

The LED assembly, as well as an electronic power control, guarantee high intensity and homogenous distribution of light. The recognition of LED-malfunction and a comprehensive monitoring function provide very high process stability.

The LED Cube 285 IC can optionally be operated with the powerful LED Spot 100 HP IC for high-intensity irradiation or with the LED Spot 100 IC for all processes which require lower intensities.

The typical **service life of a LED is more than 20.000 hours*****. The LED Cube 285 IC can be switched on and off as often as necessary, as LEDs do not require a heating or cooling phase.

The emitted wavelengths are available in 365/385/395/405/460 nm +/- 10 nm. This allows to adapt the LED unit to the existing application.

Applications

- Bonding, fixing or encapsulating components in the electronic, optical or medical-technical sector
- highly intensive UV irradiation in the biological, chemical and pharmaceutical sector

Compact dimensions

The irradiation chamber LED Cube 285 IC **with a usable irradiation area of approx. 300 x 281 x 285 mm (HxWxD)** is especially suitable for larger workpieces or workpiece carriers. The reflective inner surface and the optimized reflector geometrics provide for a **homogenous irradiation** and a high process reliability.

LED activation

The irradiation time can be optionally set between the ranges 0,01 - 99,99 sec. or 0,1 - 999,9 sec. or 1 - 9999 sec. Alternatively, continuous operation can be chosen. The operating status and the actual temperatures of the LED segments, as well as the irradiation times, can be seen on the display at one glance. The **electrical LED power can be adjusted in 1%-steps between 10 % and 100 %**. The irradiation process is started via push-button. The device monitors the operating hours of both, LED units and control unit.

Operational safety

The LED Cube 285 IC has got a safety system which guarantees that the user is safe from UV radiation. Door and LEDs are logically connected: When the door is opened during operation, the LEDs are switched-off immediately.



Advantages of LED technology

LEDs **do not emit IR radiation**. Even **temperature-sensitive materials** can be irradiated. As LEDs do not require a warm-up phase, LEDs can be switched on and off without any problems: they are **ready for immediate operation**.

Technical data

| | |
|--------------------------------------|---|
| LED service life | > 20.000 hours*** |
| adjustment range of timer (in sec.) | 0,01 - 99,99 or 0,1 - 999,9 or 1 - 9999 or continuous operation |
| wavelengths in nm | 365 385 395 405 460 |
| typ. intensity in mW/cm ² | |
| LED Spot 100 HP IC | 1.200* 2.200* 2.200* 2.200* 3.000** |
| LED Spot 100 IC | 600* 1.100* 1.100* 1.100* 1.500** |
| power supply | 115 – 230 V, |
| LED powerdrive | 50 – 60 Hz |

* measured with Hönlle UV meter and LED surface sensor, distance 0 mm

** measured with Hönlle UV meter and VIS surface sensor, distance 0 mm

*** typical lifetime under specified operating conditions



Dr. Hönlle AG UV Technology, Lochhamer Schlag 1, 82166 Gräfelfing/München, Germany
Phone: +49 89 85608-0, Fax: +49 89 85608-148. www.hoenle.de

Operating parameters depend on production characteristics and may differ from the foregoing information. We reserve the right to modify technical data. © Copyright Dr. Hönlle AG. Updated 12/20.